

Removing the Rear Sprocket Lockring

Rohloff Art#8518

To undo the lockring that holds the Gates rear sprocket on, stand behind the wheel and bend over and hold the two tools..

Bear down with your right hand on a 27mm spanner or a socket wrench.

Bear down with your left hand on the Gates tool mounted to the sprocket as in this picture.



Gate sprocket wrench